



advanced FLOW engineering

INSTALLATION GUIDE:

Part #: 50-10061

Magnum FORCE™ Intake Systems

Make: FORD

Model: Powerstroke

Engine: V8 - 7.3L Diesel

Year: 1999.5 - 2001

Parts list:

Qty:

Filter enclosure with seal	1
Splash Panel with seal	1
Splash Panel screws	4
Filter Clamp	1
Filter PN 20-40035	1

Tools Required:

- Medium flat blade screwdriver
- Medium phillips blade screwdriver

A. Installation Instructions

Prepare kit for installation;

1. Remove contents from shipping box
2. Make certain seal is installed on edge of filter enclosure & splash panel.
3. Remove filter from box & install into filter enclosure with hose clamp provided. Take care not to crush or damage filter.
4. Install splash panel & seal with (4) phillips screws provided.

Kit installation;

1. Loosen band clamp for intake hose at air filter housing.
2. Disconnect intake hose from air filter housing.
3. Unsnap clips & remove top half of filter housing & filter (store these items in a safe place for future use if needed).
4. Take kit & insert tabs of splash panel into slots on the lower half of filter housing (**photo A**) & place the kit inside the filter housing at an angle. (Tabs are to be inserted into & rest on the bottom edge of the slots. Do not hook tabs over plastic).
5. Depress spring tab slightly (**photo B**) and lower the filter enclosure down until the spring tab snaps into place.
6. Reconnect the intake hose to the filter enclosure (**photo C**).

Your installation is now complete (**photo D**). Start your engine and check for unusual noises. If you have any questions in regards to this installation, please feel free to call our toll free support line. **877-512-8111**.

Tip: To service your air filter, it is easier to remove the splash panel first for filter access and reinstallation.

Note:

Filter Cleaning and Re-oiling: When cleaning your aFe filter, use the "Restore Kit" aFe PN 90-50000 (aerosol) or PN 90-50500 (squeeze bottle).

For Filter Replacement:, use PN 20-40035 ONLY.

aFe 06-80004



Photo A



Photo B



Photo C



Photo D

Write to us:
P.O. Box 1719
Corona, Ca 92878
www.afefilters.com